



I PARTI DI RICAMBIO

2	Coperchio mobile	15	Pulsantino nero	28	Dado
3	Coperchio fisso	16	Pulsante ON/OFF	29	Rondella nylon
4	Disco abrasivo (girante)	17	Plastra sostegno Motore	30	Spruzzatore
5	Anello seeger	18	Motore	32	Pressacavo
6	Chiavetta 6x6x20	19	Scheda 700 M/T	34	Guarnizione sportello
7	Albero Inox (D=22x140)	20	Fondo Zincato	35	Rondella inox (D26-50335)
8	Paraolio (22x42x7)	21	Puleggia Motore (D40-50375)	36	Fascia abrasiva
9	Disco Ghisa AAP4	22	Cinghia	39	Guarnizione telaio
10	Telaio	23	Puleggia	40	Pomolo
11	Sportello	24	Manicotto	41	2 cuscinetti
12	Rondella	25	Carcassa pelapatate	42	Porta asta
13	Bullone	26	Temporizzatore		
14	Levetta	27	Tubo inox		

GB SPARE PARTS

2	Removable Cover	15	Black button	28	Nut
3	Fixed Cover	16	Button ON/OFF	29	Nylon washer
4	Abrasive disk (rotating)	17	Motor supporting plate	30	Sprayer
5	Seeger ring	18	Motor	32	Cable press
6	Key 6x6x20	19	Electronic card 700 M/T	34	Door seal
7	Inox shaft (D=22x140)	20	Zinc plated bottom	35	Inox washer (D26-50335)
8	Oil proof cover (22x42x7)	21	Motor pulley (D40-50375)	36	Abrasive sides
9	Cast iron disk AAP4	22	Belt	39	Shute seal
10	Shute	23	Pulley	40	Knob
11	Door	24	Sleeve	41	2 Bearings
12	Washer	25	Potato peeler carcass	42	Rood support
13	Bolt	26	Timer		
14	Lever	27	Inox tube		