



7745 A



USER'S GUIDE




**1** To raise the footrest, grasp both armrests and push forward while leaning back in the recliner.

**2** To fully recline, pull the strap loop and lean backward.

**3** To return the recliner to an upright position, pull the strap loop and sit up.

**4** To stow the footrest, push downward with your lower legs while seated.

CAUTION




• Raise footrest from full upright position only.

• Do not raise footrest from this position.

• Stow footrest with back in full upright position.

• Do not attempt to stow footrest from this position.

HOW TO ADJUST HEADREST



To adjust headrest: pull from back on both sides as shown.

Do not pull from side edge to adjust, material may tear

To return headrest back: push on both sides or use forearm to evenly move headrest back.

CAUTION  
DO NOT push in the center of the headrest as this may cause foam cushion to collapse.

PUSH HERE      PUSH HERE